

SKU: 622tr620-3

2/13/2015 Page 1 of 11

WARRANTY & TERMS

WARRANTY 5 Year Limited Warranty on Thermoplastic coated elements. Park Warehouse guarantees all items for one full year to be free of defects in workmanship or materials when installed and maintained properly. We agree to repair or replace, any items determined to be defective. Items specifically not covered by this warranty include vandalism, manmade or natural disasters, lack of maintenance, normal weathering or wear and tear due to public abuse.

Damages or loss in transit is the responsibility of the carrier, whether visible or concealed. It is the responsibility of the recipient to assure that the order is received complete. Before signing the delivery receipt, inspect the shipment immediately and completely. Note any damages or shortages on the bill of lading. Damage reports must be filed within 10 days. Park Warehouse is NOT responsible for damages or loss in transit. Title to all goods passes to the customer at the time of shipment. Park Warehouse will assist in filing claims if the freight arrangements were made by Park Warehouse at your request.

CANCELLATIONS AND RETURNS: Cancellations are only accepted with approval of Park Warehouse. No merchandise shall be returned without a Return Goods Authorization number which is issued by customer service. Any authorized merchandise must be carefully packed and received in saleable condition. A restocking charge of up to 25% will be applied to all returned goods when the error is not the fault of Park Warehouse. All returns must be shipped freight prepaid.

2/13/2015 Page 2 of 11

SAFETY WARNINGS & EQUIPMENT INSPECTION

- Owners and installers please note these safety warnings and make use of this checklist on a regular basis.
- Follow installation instructions when erecting equipment.
- Ground surfaces around equipment should be restored as needed. Concrete footings should never be exposed. Surface depth should comply with ASTM and CPSC specifications.
- Check for and repair damage caused by wear or vandalism, a major factor in injury causing situations.
- All protruding bolts should be covered or cut off and finished smooth. Sharp edges on pipes should be capped or removed. Check for bent, broken, or severly worn pipe, and replace.
- All equipment should be free of rust and repainted whenever necessary to deter rusting.
- We provide our customers with layout sheets and installation instructions. Please keep on file the specifications sheet that contains the listing of every part used.
- Never add components not intended for use with this product.
- Regular maintenance is necessary in this and all park and recreational equipment to insure the safety of the user.
- Note: Proper maintenance of equipment requires regular tightening of all bolts, nuts, and setscrews.
- Note: Regular checking of all parts, castings, etc. should be made. If a part is broken or worn, it should be replaced immediatly.
- Check to be sure all fittings are tight and that bars and pipes do not move.
- Replace all worn S-hooks. S-hooks must be completely closed. Failure to close S-hooks can result in serious injury to the user.
 NEVER reuse S-hooks.
- Test for free movement of swing hanger and other moving attached parts.
- Check for worn chains and replace them.
- A soft resilient surface should be placed under all swings extending at least twice the height of the top rail both front and back.

2/13/2015 Page 3 of 11


HARDWARE



3/8" x 1" Carriage Bolt



3/8" x 1" Machine Bolt




3/8" Washer





3/8" Kep Nut


2/13/2015 Page 4 of 11

TOOLS REQUIRED









2/13/2015 Page 5 of 11

PRODUCT SPECIFICATIONS

SV-R32 32 GALLON TRASH RECEPTACLE

Material: Top and bottom are fabricated from 11 gauge steel flat plate. Sides are fabricated from 11 gauge steel flat plate with 5/8" cold rolled rods welded to specs. Frame is made of 2" square tubing. Surface mount plates are laser cut from 1/4" steel plate.

Receptacle Coating: Oven fused functionalized polyethylene copolymer-based thermoplastic. Fluidized bed coating application with superior mechanical performance, impact resistance and UV-stability.

Receptacle Dimensions: 28" square x 32" high x 32 gallon capacity.

Hardware: Mounting hardware not included.

RB-32-08 32 GALLON RAIN BONNET TOP

Material: Top plate shall be fabricated from 18 gauge steel flat, spun to form. Vertical posts are 1/2" diameter steel rods. Bonnet top shall be fabricated from 20 gauge steel flat, spun to form. All electrically MIG welded.

Coating: Oven fused functionalized polyethylene copolymer-based thermoplastic. Fluidized bed coating application with superior mechanical performance, impact resistance and UV-stability.

Receptacle Dimensions: Center opening shall be 8" inside diameter. The overall dimensions shall be 24" diameter x 11" high.

PL-32: Made of Heavy Duty Plastic.


Overall Dimensions Including Top: 28" Square x 40-5/8" High x 32 gallon capacity.

2/13/2015 Page 6 of 11

COMPONENTS


Optional Surface Mount Hardware: 3/8" x 3-1/2" Concrete Expansion Anchor Bolts (Not Included)

ITEM NO. PartNo DESCRIPTION QTY. 1 PL-32 32 Gal. Liner 1 2 01-05-0057 Sav Receptacle Bottom Plate 1 3 01-05-0056 Sv Flat Top Holder 1 4 T-SV32-R Sav Receptacle 32 Frame RH 2 5 T-SV32-L Sav Receptacle 32 Frame LH 2 6 33-02-0008 3/8" Flat Washer (SS) 20 7 33-06-0042 3/8" x 1" Carriage Bolt (SS) 4 8 33-03-0013 3/8" Kep Nut (SS) 4 9 33-06-0056 3/8" x 1" Machine Bolt (SS) 16 10 RBR-32-08 32 Gallon Rolled Rain Bonnet with a 8" opening 1 11 01-05-0076 palmetto rod receptacle side panel 4				
2 01-05-0057 Sav Receptacle Bottom Plate 1 3 01-05-0056 Sv Flat Top Holder 1 4 T-SV32-R Sav Receptacle 32 Frame RH 2 5 T-SV32-L Sav Receptacle 32 Frame LH 2 6 33-02-0008 3/8" Flat Washer (SS) 20 7 33-06-0042 3/8" x 1" Carriage Bolt (SS) 4 8 33-03-0013 3/8" Kep Nut (SS) 4 9 33-06-0056 3/8" x 1" Machine Bolt (SS) 16 10 RBR-32-08 32 Gallon Rolled Rain Bonnet with a 8" opening 1	—	PartNo	DESCRIPTION	QTY.
3 01-05-0056 Sv Flat Top Holder 1 4 T-SV32-R Sav Receptacle 32 Frame RH 2 5 T-SV32-L Sav Receptacle 32 Frame LH 2 6 33-02-0008 3/8" Flat Washer (SS) 20 7 33-06-0042 3/8" x 1" Carriage Bolt (SS) 4 8 33-03-0013 3/8" Kep Nut (SS) 4 9 33-06-0056 3/8" x 1" Machine Bolt (SS) 16 10 RBR-32-08 32 Gallon Rolled Rain Bonnet with a 8" opening 1	1	PL-32	32 Gal. Liner	1
4 T-SV32-R Sav Receptacle 32 Frame RH 2 5 T-SV32-L Sav Receptacle 32 Frame LH 2 6 33-02-0008 3/8" Flat Washer (SS) 20 7 33-06-0042 3/8" x 1" Carriage Bolt (SS) 4 8 33-03-0013 3/8" Kep Nut (SS) 4 9 33-06-0056 3/8" x 1" Machine Bolt (SS) 16 10 RBR-32-08 32 Gallon Rolled Rain Bonnet with a 8" opening 1	2	01-05-0057	Sav Receptacle Bottom Plate	1
5 T-SV32-L Sav Receptacle 32 Frame LH 2 6 33-02-0008 3/8" Flat Washer (SS) 20 7 33-06-0042 3/8" x 1" Carriage Bolt (SS) 4 8 33-03-0013 3/8" Kep Nut (SS) 4 9 33-06-0056 3/8" x 1" Machine Bolt (SS) 16 10 RBR-32-08 32 Gallon Rolled Rain Bonnet with a 8" opening 1	3	01-05-0056	Sv Flat Top Holder	1
6 33-02-0008 3/8" Flat Washer (SS) 20 7 33-06-0042 3/8" x 1" Carriage Bolt (SS) 4 8 33-03-0013 3/8" Kep Nut (SS) 4 9 33-06-0056 3/8" x 1" Machine Bolt (SS) 16 10 RBR-32-08 32 Gallon Rolled Rain Bonnet with a 8" opening 1	4	T-SV32-R	Sav Receptacle 32 Frame RH	2
7 33-06-0042 3/8" x 1" Carriage Bolt (SS) 4 8 33-03-0013 3/8" Kep Nut (SS) 4 9 33-06-0056 3/8" x 1" Machine Bolt (SS) 16 10 RBR-32-08 32 Gallon Rolled Rain Bonnet with a 8" opening 1	5	T-SV32-L	Sav Receptacle 32 Frame LH	2
8 33-03-0013 3/8" Kep Nut (SS) 4 9 33-06-0056 3/8" x 1" Machine Bolt (SS) 16 10 RBR-32-08 32 Gallon Rolled Rain Bonnet with a 8" opening 1	6	33-02-0008	3/8" Flat Washer (SS)	20
9 33-06-0056 3/8" x 1" Machine Bolt (SS) 16 10 RBR-32-08 32 Gallon Rolled Rain Bonnet with a 8" opening 1	7	33-06-0042	3/8" x 1" Carriage Bolt (SS)	4
10 RBR-32-08 32 Gallon Rolled Rain Bonnet with a 8" opening 1	8	33-03-0013	3/8" Kep Nut (SS)	4
10 RBR-32-08 opening	9	33-06-0056	3/8" x 1" Machine Bolt (SS)	16
11 01-05-0076 palmetto rod receptacle side panel 4	10	RBR-32-08		1
	11	01-05-0076	palmetto rod receptacle side panel	4



2/13/2015 Page 7 of 11


STEP 1



Attach the Rod Panels to the Sav Frames as shown using specified hardware.

2/13/2015 Page 8 of 11


STEP 2



Instert the Sav Bottom Plate into the assembly as shown and fasten using specified hardware.

2/13/2015 Page 9 of 11

STEP 3



Place 32 Gallon Liner into assembly, then place Sav Top Holder and Rain Bonnet on top of the assembly as shown.

2/13/2015 Page 10 of 11

OVERALL DIMENSIONS 28 1/8" Ø24" -Ø16" 40 5/8" 29 3/8"

2/13/2015 Page 11 of 11