





E-Series 46" Round Picnic Table

Model #: 624pt120


Top View:



Front View:



Side View:





E-Series 46” Round Picnic Table

Model #: 624pt120

Safety Warnings & Equipment Inspection:


- ❖ Owners and installers please note these safety warnings and make use of this checklist on a regular basis.
- ❖ Follow installation instructions when erecting equipment.
- ❖ Ground surfaces around equipment should be restored as needed. Concrete footings should never be exposed. Surface depth should comply with ASTM and CPSC specifications.
- ❖ Check for and repair damage caused by wear or vandalism, a major factor in injury causing situation.
- ❖ All protruding bolts should be covered or cut off and finished smooth. Sharp edges on pipes should be capped or removed. Check for bent, broken, or severely worn pipe, and replace.
- ❖ All equipment should be free of rust and repainted whenever necessary to deter rusting.
- ❖ We provide our customers with layout sheets and installation instructions. Please keep on file the specifications sheet that contains the listing of every part used.
- ❖ Never add components not intended for use with this product
- ❖ Regular maintenance is necessary in this and all park and recreational equipment to ensure the safety of the user.
- ❖ Note: Proper maintenance of equipment requires regular tightening of all bolts, nuts, and setscrews.
- ❖ Note: Regular checking of all parts, castings, etc. should be made. If a part is broken or worn, it should be replaced immediately.
- ❖ Check to be sure all fittings are tight, and that bars and pipes do not move.
- ❖ Replace all worn S-hooks. S-hooks must be completely closed. Failure to close S-hooks can result in serious injury to the user. NEVER reuse S-hooks.
- ❖ Test for free movement of swing hanger and other moving attached parts.
- ❖ Check for worn chains and replace them
- ❖ A soft resilient surface should be placed under all swings extending at least twice the height of the top rail both front and back.




E-Series 46" Round Picnic Table

Model #: 624pt120


Hardware



5/16" x 1"
Machine Bolt



5/16" Washer







5/16" Kep Nut



E-Series 46" Round Picnic Table

Model #: 624pt120

Tools Required:





E-Series 46" Round Picnic Table

Model #: 624pt120

Product Highlights


Top & Seats:	11-gauge die formed angle frame 1" x 1-7/8" with 3" radius corners. 3/4" #9 Steel expanded metal. 7-gauge x 1-1/2" flat bar center support and mounting bracket understructure. Top is additionally supported to the outer frame with 7-gauge x 1-1/2" flat bar. Electrically MIG welded.
Coating:	Oven fused functionalized polyethylene copolymer-based thermoplastic. Fluidized bed coating application with superior mechanical performance, impact resistance and UV-stability.
Frame:	1-5/8" O.D. x 14-gauge pre-galvanized structural steel tubing. Cross braces 1" O.D. x 16-gauge pre-galvanized steel tubing. Brace attachment points 1-1/2" x 2" x 3/16" steel flat bar. Top mountings points are 7-gauge 2" x 2" die formed angle. Seat mounting points are 7-gauge x 1-1/2" die stamped steel flat bar. Legs are bent over mandrel through the bend radius producing a wrinkle free bend. All electrically MIG welded.
Frame Coating:	Electrostatic powder coated application oven cured.
Hardware:	All stainless-steel hardware fasteners.
Dimensions:	Top is 46" x 30" high. Seats are 12" wide x 41-1/2" long x 18" high. Outside to outside dimensions of 4 seat table is 82" x 82".



E-Series 46" Round Picnic Table

Model #: 624pt120

Components




Item No.	Part No.	Description	QTY
1	T-V46RD-T	46" Round Expanded Top	1
2	T-V36RD-S	3' Expanded Round Seat	4
3	P-01-04-0121	Extension Tab	4
4	P-V358-L	Vinyl Leg L	4
5	P-V358-R	Vinyl Leg R	4
6	33-06-0082	5/16" x 1-1/2" Button Torx Bolt (SS)	72
7	33-05-0029	5/16" x 1" Machine Bolt (SS)	36
8	33-03-0012	5/16" Kep Nut (SS)	36
9	P-01-04-0122	Cross brace w/ umbrella tube	1



E-Series 46" Round Picnic Table

Model #: 624pt120

Instructions



Step 1:


- ❖ Attach the extension tabs to the 46" round top using specified hardware.



E-Series 46" Round Picnic Table

Model #: 624pt120

Instructions



Step 2:

- ❖ Attach the legs to the extension tabs using specified hardware.



E-Series 46" Round Picnic Table

Model #: 624pt120

Instructions

Step 3:

- ❖ Attach the cross brace between the table legs shown using specified hardware.





E-Series 46" Round Picnic Table

Model #: 624pt120

Instructions

Step 4:

- ❖ Attach the 3' seats to the legs using specified hardware.

